All-Terrain Cruiser User Guide

Go to English

Guide de l'utilisateur du Cruiser tout-terrain

Aller au français

RAISE THE WILD
POUR L'AMOUR DE LA NATURE

WELCOME TO YOUR CRUISER

We hope you enjoy your adventures with your Cruiser. Exploring, camping and building the Cruiser Trailer review these instructions carefully and contact Customer Service if you have any questions.

⚠ WARNING

IMPORTANT: READ THESE INSTRUCTIONS FOR ASSEMBLY, USE AND CARE.
FAILURE TO FOLLOW THESE INSTRUCTIONS - FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH. CONTACT CUSTOMER SERVICE BEFORE USE.

- Use a harness on even or uneven terrain.
- Do not use in water.
- The product is intended for use on land only. Do not use on water.
- Do not exceed the maximum capacity.
- Check that the Cruiser is used and set up as designed.
- Ensure that all the locking devices are engaged before use.
- Do not leave a Cruiser unattended on a slope or in areas where unfolding and folding the product could be hazardous to people or property.
- Check that the Cruiser is used and set up with attachment devices are correctly engaged before use.
- Do not use the Cruiser in areas where there are restrictions to 30 kg (66 lbs) each 90 kg (or 1 lb for 3 lbs) of weight.
- Do not use the Cruiser beyond its limits with other than a Cruiser Trailer.
- Do not exceed the Cruiser's maximum weight limit.
- To prevent injury, ensure that children are fitted with their arms and legs inside the Cruiser while in motion.
- Use only the Cruiser's manufacturer's recommended tow bar, or equivalent, or, if special tow bar is required, one that has been approved by the manufacturer in order to hitch to the Cruiser.
- Never pack the Cruiser on a hill with children inside.
- Total weight load recommended for the Cruiser is 90 kg (200 lbs).
- Always make sure the Cruiser is fully open and locked before use.
- Do not use the Cruiser if any parts are missing or the Cruiser with products not supplied by the manufacturer or its authorised dealers.
- Do not use in extreme high or low temperatures.
- To avoid serious injury from falling or sliding out, ensure that children are secured in the Cruiser using the harness, and should always use complete Cruiser harness.
- Do not use the Cruiser without rear wheel safety flags to prevent injury from being hit by vehicles from moving wheels.
- Do not use the Cruiser as a pull mode. Do not attempt to pull children.
- Do not use the Cruiser with other than approved Cruiser Trailer.
- Do not use the Cruiser without rear wheel safety flags to prevent injury from being hit by vehicles from moving wheels.
- Do not use the Cruiser as a pull mode. Do not attempt to pull children.
- Do not use the Cruiser with other than approved Cruiser Trailer.
- Do not use the Cruiser without rear wheel safety flags to prevent injury from being hit by vehicles from moving wheels.
- Do not use the Cruiser as a pull mode. Do not attempt to pull children.
- Do not use the Cruiser with other than approved Cruiser Trailer.

The Cruiser Overview

The Cruiser has been crafted with the finest workmanship and highest quality materials. Thoroughly tested and designed to meet or exceed all safety and highest quality standards. Enjoy the Cruiser for years to come.

01 High Performance Rubber Handle Grips
02 Pre-Stretching Handle Bar Mechanism
03 Removable Front Anti-Trick Tray
04 Tow Bar Connection Point
05 Safety Harness
06 Rugged Rear Wheels
07 Rear Safety Flags
08 Accessory Mounts With Plugs
09 Rear Bell Bell Bracket
10 Rear Bell Bell Bracket
11 Rear Cup Holder
12 Removable Cup Holder
13 Rear Reflectors
14 Handle Lock
15 Foot Brace
16 3 Point Seat Harness
17 Removable Tray Bell Insert
18 Side Storage Pockets

Choosing, Maintenance, and Check-Up

Choosing the Cruiser or a location that is out of direct sunlight is recommended to prevent discoloration. If the Cruiser is used outdoors, we recommend frequent cleaning and maintenance.

If the Cruiser's chassis parts have been exposed to salt water, we recommend that they be thoroughly rinsed with fresh water and dried to prevent rust and corrosion.

If the Cruiser has been exposed to sand, use a soft brush to remove the sand from the chassis. Sand can cause the compressed spring and the sand to wear out the chassis and the wheel axle.

If the Cruiser is in need of an all-year wash, remove the chassis and wheel axle and soak them in a bucket of water overnight and then rinse with fresh water and dry thoroughly.

Contact Customer Service center or the Cruiser's manufacturer for more information. **CARE, CLEANING AND WHEELS**

Wipe with a clean cloth and a mild detergent and dry thoroughly. DO NOT Wipe with a chemical solvent. **SOFT SEED FABRICS**

Wipe with a clean cloth and a mild detergent and dry thoroughly. DO NOT Wipe with a chemical solvent. Wipe the removed for hand washing in cold water with mild detergent. Do not bleach. Do not tumble dry. Do not iron. Do not dry clean. **ALUMINUM FRAME**

Check TRAY AND CUP HOLDERS

Wipe in a cloth or with a hose, or wipe with a damp cloth and a mild detergent and dry thoroughly. DO NOT Wipe with a chemical solvent. **HARNESS AND SEAT**

Check all safety devices, locks and harnesses for wear and tear and operation. Repair and replace the harness if it is worn or damaged. Do not use. Only hear replacement parts should be used. If the Cruiser is used in the original country of purchase. The warranty is valid for 12 months and cannot be set up for the country in which the items were purchased. Please contact the Cruiser's manufacturer's service center or the Cruiser's manufacturer's service center.

Do not provide replacement parts or conduct repairs of harness parts yourself. Only the Cruiser's manufacturer's service center or the Cruiser's manufacturer's authorised dealers are authorised to provide replacement parts and conduct repairs.

For full set of warranty details, visit gocruiser.com

SETTING UP & USING THE CRUISER

WHEELS

OPEN THE CRUISER FRONT

Pull up the Cruiser between towers and swing handle up to locked position. Pull side panels up followed by front and rear locks into locked position.

WHEELS

REAR WHEELS: Press button in center of wheel and pull out the frame and lock into position.
FRONT SWIVEL WHEELS: Attach front wheels and click into place.

ADJUST THE TELESCOPIC HANDLE

Adjust harness and shoulder straps to fit.

ADJUSTING THE TELESCOPIC HANDLE

Pull the handle up and down and press. Release button to adjust the handle.

SEAT

SEAT FRONT SWING

To set forward, press gently until it clicks.
To release handle, gently push the button.

ADJUST 3 POINT HARNESS

Adjust harness and shoulder straps to fit.



ADJUSTING THE TELESCOPIC HANDLE

Pull the handle up and down and press. Release button to adjust the handle.

SEAT

LOWER WHEELS

PUSH MODE: Lower handle for upright.
PUSH ALONG MODE: Lock handle for upright.

LOWER WHEELS (CONT.)

PULL MODE: Ensure and stop handle too.

STORAGE & STORAGE

Remove accessories. Lift release button on the back of the handle and push down and fold the handle. Hold both side panel down and fold up. Pull the handle and lay down to fold.

STORAGE (CONT.)

Place in a level and flat surface when storing in a storage position.

REMOVING WHEELS

Remove wheels for ultimate compactness.

The Cruiser can fold with wheels and handle attached. Remove wheels for ultimate compactness and horizontal position. Ensure stability prior to leaving unattended.

FR
DEVENIR
A VOIR

Vous espérons que vous apprécierez votre Cruiser. Pour tirer le plus grand bénéfice de votre Cruiser, veuillez lire attentivement les instructions avant de l'assembler et de l'utiliser. Conservez ce guide pour votre famille ensuite.

⚠ AVERTISSEMENT

LIRE ATTENTIVEMENT TOUTES LES INSTRUCTIONS AVANT DE VOUS ASSEMBLER.
NE PAS UTILISER CE PRODUIT AVANT D'AVOIR ÉTÉ ENTIÈREMENT ASSEMBLÉ. SUIVRE LES INSTRUCTIONS D'ASSEMBLAGE DU DÉCLINAISON GRAVES DE LA CHAUSSURE. UTILISATION DE PIÈCES DE RECHANGE TROUVÉES DANS LA QUINCAILLERIE UNIQUEMENT.

- Ne pas utiliser ce produit à l'extérieur ou sur une surface inclinée.
- Ne pas utiliser ce produit sur une surface de moins de 3 m.
- Toujours utiliser le système de chaussure approprié pour le type de surface sur lequel vous roulez.
- Essayez d'avoir exclusivement tous les roulements de chaussure.
- Pour éviter toute blessure, ne pas utiliser ce produit sur des surfaces humides.
- Ne pas utiliser ce produit sur des surfaces de plus de 10 pieds sur 10 pieds. Le fabricant ne peut pas être responsable d'blessures du village quelle qu'en soit la cause.
- Le Cruiser doit être utilisé par un adulte. Ne pas laisser les enfants jouer avec le Cruiser. Le Cruiser présente le danger suivant : Le Cruiser est conçu pour rouler sur des surfaces planes et lisses. Le Cruiser ne convient pas à des enfants de moins de 6 ans, et un village seul, tout en l'utilisant. Le Cruiser ne convient pas à des enfants ayant moins, ou plus, de 6 pieds de hauteur. Le Cruiser présente le danger suivant : Le Cruiser peut se renverser. Le Cruiser présente le danger suivant : Le Cruiser peut se renverser si vous vous appuyez sur le côté du Cruiser. Le Cruiser présente le danger suivant : Le Cruiser peut se renverser si vous le tirez par le bras.
- Ne pas laisser le Cruiser sans surveillance.
- Ne pas gonfler le Cruiser au-delà de la pression indiquée sur le pneu.
- Ne pas utiliser le Cruiser dans des conditions de pluie, de neige, de brouillard, de vent ou de gel.
- Ne pas utiliser le Cruiser à proximité de sources de chaleur ou de flammes.
- Toujours porter des vêtes d'ouvert dans pieds et des chaussures appropriées lors de l'utilisation du Cruiser. Ne pas porter de chaussures de ville ou de talons hauts.
- Ne pas porter de bijoux.
- Ne pas utiliser le Cruiser dans un village ou dans un village.
- Ne pas utiliser le Cruiser dans des zones de circulation ou de trafic