Cruiser City XL User Guide

Go to English

Guide de l'utilisateur du Cruiser de ville TG

Aller au français

RAISE THE WILD
POUR L'AMOUR DE LA NATURE

EN WELCOME TO VEER

We hope you enjoy your adventures with your Cruiser. Please read carefully and bulletproof your ride. Please review these instructions carefully and contact us if you have any questions, we are here to help!

IMPORTANT: READ THESE INSTRUCTIONS FOR ASSEMBLY & USE

⚠ WARNING:

NEVER LEAVE CHILDREN UNATTENDED. FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR DEATH. READ INSTRUCTION MANUAL BEFORE USE.

- Use a helmet and wear knee and elbow pads at all times.
- Ensure the ground is not suitable for children under 8 years.
- Always use the restraint system.
- Do not use the product near any moving or standing vehicles, or near any other hazardous environments.
- Do not use the product on ice, snow or wet surfaces.
- Do not use the product on slopes or steep inclines.
- Do not let your child play with the product.
- Do not let your child use the product if it is damaged, or if any components are currently unapproved for use.
- The Veer Cruiser XL weighs up to four children from 10 kg/22 lbs to 30 kg/66 lbs and a maximum height of 174 cm (68 in) each (180 kg or 396 lbs total).
- Do not let your child use the product if it exceeds the maximum weight or height limit, or if it is underweight.
- Do not let children, children mount remain seated until their wheels are completely stopped, and wait for adults to help.
- Do not let children operate if manufacturer's recommended age is exceeded, or if prompted by an accessory other than the recommended one.
- Do not let children under 8 years old use the product.
- Never pack the product in a way that could cause injury to people or animals.
- The trailer must be locked while exiting the child seat, and the child seat must be in the upright position when the trailer is locked.
- Do not use the product in rain.
- Do not use the product in conditions or modifications to the product that are not approved or recommended by manufacturer, as this may cause instability or injury. Only use the product in conditions and with modifications that are approved by manufacturer.
- Do not use the Cruiser XL without rear wheel suspension, as this may cause instability or injury.
- Always keep fingers away from moving parts.
- Do not let children ride on the trailer without the child seat, or without the safety harness.
- Do not let children ride on the trailer without the safety strap.
- Do not let children operate if manufacturer's recommended age is exceeded, or if prompted by an accessory other than the recommended one.
- Never pack the product in a way that could cause injury to people or animals.
- The trailer must be locked while exiting the child seat, and the child seat must be in the upright position when the trailer is locked.
- Do not use the product in rain.
- Do not use the product in conditions or modifications to the product that are not approved or recommended by manufacturer, as this may cause instability or injury. Only use the product in conditions and with modifications that are approved by manufacturer.
- Do not use the Cruiser XL without rear wheel suspension, as this may cause instability or injury.
- Always keep fingers away from moving parts.
- Do not let children ride on the trailer without the child seat, or without the safety harness.
- Do not let children ride on the trailer without the safety strap.
- Do not let children operate if manufacturer's recommended age is exceeded, or if prompted by an accessory other than the recommended one.
- Never pack the product in a way that could cause injury to people or animals.

The Cruiser XL Overview

The Cruiser XL has been crafted with the finest materials and components, ensuring durability and comfort. Each component has been meticulously designed to give the highest performance, superior functionality and ultimate comfort.

01 High Performance Aluminum Alloy Frame
02 Telescoping Handle Bar Mechanism
03 Adjustable Handle Bar Grips
04 Integrated Cup Holder Front Seat
05 Safety Fastener
06 Safety Harness Buckle
07 Accessory Mounts
08 Accessory Mounts With Plugs
09 Foot Rest And Grips
10 Fabric Safe Panels
11 Adjustable Footrest
12 Removable Cup Holder
13 Aluminum Frame
14 Rear Wheels
15 Foot Rests
16 3-Point Seat Harness
17 Adjustable Seat Harness
18 Rear Storage Pockets

Cleaning, Maintenance, and Check-Up

Keep the Cruiser XL in a manner that is out of direct sunlight and environmental elements. If the Cruiser XL is not used for an extended period of time, it is recommended that you:

- Remove and hand wash in cold water with mild soap and let dry. Do not use any chemical cleaners. Refer to care or storage TIP REPORT Service, or visit the Veer website.
- Check all parts and fasteners are in good condition.
- Lubricate the Cruiser XL bearings and joints with a light oil.
- Check all parts and fasteners are in good condition.
- Lubricate the Cruiser XL bearings and joints with a light oil.

Time for a Check Up

The Cruiser XL requires some basic user maintenance. Regularly check all connecting hardware (nuts, bolts, screws) and tighten if necessary. Check the tire pressure is adequate and inspect the wheels for cracks and signs of wear.

Check all safety devices, locks and harnesses for correct and secure function. Remove dirt and grime from the Cruiser XL with a damp cloth.

Keep the Cruiser XL parts in the original country of purchase. The warranty is valid for two years from the date of purchase, subject to the terms of the provided. Conditions may vary. Gear will not ship outside the country of purchase, or to a PO box or military address.

Gear will provide replacement parts on request. Customers are responsible for shipping costs. Gear may exercise the option to provide repair or a replacement part. Some parts may be replaced with similar or equivalent parts if the original part is no longer available.

For full set of warranty details, visit gearcuse.com

SETTING UP & USING THE CRUISER

OPEN THE CRUISER XL FRAME

Pull up on both handles to open the frame and lock up to locked position. Pull safety pounds up followed by Foot off and lock into locked position.

02.

INSTALL SAFETY FENDERS

Place safety fenders on the front the anti-squeeze. Ensure the safety fenders are fitted "Left Side Cruiser" and "Right Side Cruiser" and "Left" and "Right". Make sure not at the bottom of the safety fenders are secured in open mid-to rear axle position.

03.

INSTALL REAR WHEELS

Place the rear wheels on the axle (wheel axle is inserted into axle). Ensure the wheels are secured and slide into frame until you hear a click. Check that wheel is locked in place by pushing the wheel down from the top.

04.

INSTALL FRONT SWIVEL WHEELS

Attach front swivels with you have a click.

05.

INSTALL TRAY & CUP HOLDERS

Tray must be centrally located on the seat and secured with the cup holder. Ensure some of the cups and cup holder are secured in the tray. Ensure the tray and cup holder are fitted to the Cruiser.

06.

ADJUST THE TELESCOPIC HANDLE

Unlock to adjust height and lock. Release dial to adjust back handle.

07.

FOOD BRAKES

Push down to lock and release.

08.

FOLDING & STORAGE

Release handle and lock the frame with a click.

09.

REMOVING WHEELS

Remove the wheels in a direct compartments. The Cruiser XL can be lifted or carried using the handle, by frame, or by holding the handle where in the down position. Ensure the frame is locked safely and is transport position.

FR

REMARQUE À LIRE

Tous exemples que vous apercevez dans ce manuel ne sont pas à l'échelle ou du plan à respecter. Ce manuel d'utilisation a été conçu pour vous expliquer seulement les instructions d'installation et d'utilisation. Les dimensions et les proportions ne sont pas

IMPORTANT - CONSERVER LE INSTRUCTIONS D'INSTALLATION ET D'UTILISATION

⚠ MISE EN GARDE

LIRE ATTENTIVEMENT LES INSTRUCTIONS DE SÉCURITÉ ET D'INSTALLATION AVANT DE TENTER DE MONTER, DÉMONTER, ÉTALER OU ÉTENDRE LE BRASSOIR. LE NON-RESPECT DES INSTRUCTIONS D'INSTALLATION ET DE SÉCURITÉ PEUT ENTRAÎNER DES BLESSURES GRAVES OU LA MORT.

- Ne pas utiliser le système de brassoir si quelque chose semble mal ajusté ou endommagé.
- Ne pas utiliser le système de brassoir si des pièces sont manquantes ou cassées.
- Toujours utiliser le système de brassoir conformément à son usage prévu et selon les instructions du fabricant.
- Ne pas modifier le système de brassoir.
- Ne pas utiliser le système de brassoir si vous ne pouvez pas vous tenir en toute sécurité à votre place.
- Ne pas utiliser le système de brassoir si vous pesez plus de 136 kg (300 lb) ou si votre taille mesure plus de 1,90 m (6'2") ou moins de 1,52 m (5'0").
- Ne pas utiliser le système de brassoir si vous pesez moins de 68 kg (150 lb) ou si votre taille mesure plus de 1,90 m (6'2") ou moins de 1,52 m (5'0") sans l'adaptateur de siège d'auto pour bébé de Graco® (vendu séparément).
- Afin d'éviter des blessures, les enfants doivent toujours être attachés à l'aide du système de sécurité Tri-Secure® lorsque le brassoir est utilisé.
- Ne pas utiliser le système de brassoir si vous ne vous sentez pas à l'aise ou si vous ne vous sentez pas responsable du trajet.
- Ne pas utiliser le système de TC sur une pente si vous ne vous sentez pas à l'aise ou responsable de votre sécurité.
- Ne pas laisser des renseignements de TC sur une pente si vous ne vous sentez pas à l'aise ou responsable de votre sécurité.
- Toujours placer le système de TC sur un terrain plat et stable.
- Ne pas laisser des renseignements de TC sur un terrain plat et stable.
- Ne pas modifier ou tenter de modifier le système de TC.
- Ne pas utiliser le système de TC si vous ne vous sentez pas à l'aise ou responsable de votre sécurité